

HARNESS FITTING GUIDE


EVERYDAY HARNESSES

- / LINE HARNESS 5.0
- / LINE HARNESS GRIP

Tips!

If you find it hard to take the harness on/off, twist it sideways when pulling it over your dog's head.

Lock the chest straps by threading the end of the strap back through the sliplock.



1 | NECK

You should be able to fit at least two fingers vertically between the top of your dog's neck and the harness for a medium sized dog (sizes 4-6). A bit less for smaller dogs, more for bigger dogs.

Important! Fingers on top of each other, between the dog's neck and harness.



2 | ARMPITS

Make sure there is room for your dog to move freely.

3 | CHEST

For medium sized dogs, you should be able to fit at least two fingers vertically between your dog's chest and the harness. Adjust on both sides, as even as possible.

