

HARNESS FITTING GUIDE

PULLING HARNESSES

/ FREEMOTION HARNESS 5.0

/ COMBINED HARNESS

When going through this checklist, your dog should stand up, and the harness should be held in a pulling position.

Tips!

If you find it hard to take the harness on/off, twist it sideways when pulling it over your dog's head. You can also loosen the side straps and open the velcro at the back if needed.

NECK

You should be able to fit two fingers vertically between the top of your dog's neck and the harness for a medium sized dog (sizes 4-7). A bit less for smaller dogs, more for bigger dogs. A pulling-harness should be quite snug around the neck!



Important!

Fingers on top of each other, between the dog's neck and harness.

DEPTH

With the side straps, you adjust the depth to fit your dog's chest. For medium sized dogs, you should be able to fit two fingers vertically between your dog's chest and the harness.

ATTACHMENT POINT

Adjust so that the blue rope you attach the line to starts right above the base of your dog's tail.



CHEST BONE

The lowest point of the neck opening should be at your dog's chest bone. The position can be adjusted with the side straps.

ARMPITS

Make sure there is room for your dog to move freely.

RIBS

The side straps should lie on your dog's ribs, not further back than the last rib bone.